



Electrical tables - information

Before use:

When the monitor, cpu or laptop and other accessories have been placed on the table, the table should be reset:

- 1) Lower the table to its lowest position with the minus button
- 2) Release the button
- 3) Press the minus button again
- 4) Wait for the table to move slightly and then release the button
- 5) Use the plus button and drive the table to the desired height. Your table is now ready for use.

If your table has been out of power - run the "before use" procedure.

Use:

We recommend that you vary as much as possible between sitting and standing work position. Experience shows that those who vary the most have minor problems with their back and neck.

Downtime:

If for any reason your table does not work properly, do the following: Try the "Before use" procedure - if this does not work - remove the power cord and press any of the buttons and then try again with "before use" - procedure. If this does not work, contact service personnel.

Moving of electrically height-adjustable table:

If you have to move the table without service personnel present - lift table in the table top with the legs all the way up from the floor and place table in the desired position. The table must NOT be pushed, turned or dragged when the legs are in the floor. This destroys the height and lower function of the table.

Horreds Möbel AB, Varbergsvägen 448, 519 30 HORRED,
Tel +46 (0) 320 184 00 Email: info@horreds.se
Org.nr. 556365-1974
www.horreds.se