
SIGLO SLIDING TABLE TOP


HOS EDS

M439-3





MF6S M6x12 8pcs. Used between T-foot and elictrical leg.



20220517

SIGLO SLIDING TABLE TOP




 \prod

Used between wheel and L-square.



Turn the table stand over. Attach wheel to the L-square.






STFX 4,5x45 2pcs. Used between transformer and table top.

STFX 4,0x35 2pcs.
Used between elictrical lock and table top.





Attach the transformer to the table top with the STFX 4,5x45 screw. *Attach the lock to the tabletop with the STFX 4,0x35 screw.. See separate installation guide
Attach the tabletop to the stand with the STRX 5,0x20 screw.



2022051

SIGLO SLIDING TABLE TOP

M439-3



STFX 4,0x20 2pcs. Used between controller and table top. \prod

F6S M4x10 4pcs. Used between expanders and fastening plate. \square

Systemskruv 6,2x13 pcs. Used between fastening plate and table top.

Used between stop angels and table top and between locking angel and table top.

K6S M4x10 2pcs.

Used between locking pin and locking angel.




Place tabletop with the upside down. N.B! place something under the tabletop to protect the surface.

Attach the controller with the STFX 4,0x20 screw, place cable in groove. Attach rubber pieces to the stop angles and screw them to the table with the STFX 3,5x15 screws. Attach the fastening plates with the 6,2x13 screws.

Attach expanders with the F6S M4x10. The hole at the back hooks to the pinon the fastening plate. Apply the plastic heel.

*Screw the locking pin to the locking angel and then screw locking angel to table top.



*Only if the table is lockable. Lock is ordered seperately.




Metal plate 8,4X16X1,5 6pcs. Place between P6SMx12 and expanders.



P6S M6x12 6st. Used between expanders and stand.



Place tabletop on the stand. Place the metal plate over the lowered holes of the expanders. Attach the expanders to the top with the P6S M6x12 screws.



SIGLO SLIDING TABLE TOP

M439-3






Montageskruv 4,2x19 2pcs. Used between felt tray and frame..



STRX 5,0x17 8pcs. Used between felt tray and table top.



Slide the felt tray up towards the tabletop. Attach the tray to the frame with the 4,2x19 screw. Attach the tray to the tabletop with the STRX 5,0x17 screw.



Use the controller to lower the table to it's most bottom position and hold the button until the legs run into end stop. It will run approx. 3mm out again and then slowly run in again. Do not release the down button until the movement has stopped completely. Use the controller to raise the table to its highest position, lower it by approx 10 cm and then up again 3 times.

20220517